

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	4X4	●	●	●	●	○
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	ABS	●	●	●	●	0008
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	GEM	●	●	●	●	000A 000F
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●	○
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	PAM	●	●	●	●	○
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	PCM	●	●	●	●	0009 0023 0025 00C5
(A11 MY05)	2.3L	DURATEC-HE / I4	2005 MY	RCM	●	●	●	●	000C
(A11 MY05)	3.0L	4V	2005 MY	4X4	●	●	●	●	○
(A11 MY05)	3.0L	4V	2005 MY	ABS	●	●	●	●	0008
(A11 MY05)	3.0L	4V	2005 MY	GEM	●	●	●	●	000A 000F
(A11 MY05)	3.0L	4V	2005 MY	IC	●	●	●	●	0005
(A11 MY05)	3.0L	4V	2005 MY	PAM	●	●	●	●	○
(A11 MY05)	3.0L	4V	2005 MY	PCM	●	●	●	●	0009 0023 0025 00C5
(A11 MY05)	3.0L	4V	2005 MY	RCM	●	●	●	●	000C
626 / 626 WAGON / TELSTAR	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	1.8L	FP	2000 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	1.8L	FP	1997 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	1.8L	FP	1997 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	1.8L	FP	1999 MY	ABS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	1.8L	FP	1999 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	2000 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	ABS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	ABS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	1999 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	FS	2001 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1997 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 MY	ABS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	RF-T	2000 MY	ABS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.0L	RF-T	2000 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.5L	KL	1997 MY	PCM	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.5L	KL	2000 MY	PCM	●	●	●	●	0023 0025
626 / 626 WAGON / TELSTAR	2.5L	KL	2001 MY	ABS/TCS	●	●	●	●	○
626 / 626 WAGON / TELSTAR	2.5L	KL	2001 MY	PCM	●	●	●	●	0023 0025
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	4X4	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	ABS	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	EATC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	EPS	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	ICCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	LCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	MPM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	PCM	●	●	●	●	0009
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RKE	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	RVM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	TCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.5L	L5	2007 MY	TCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	ABS	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	EATC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	EPS	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	ICCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	LCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	MPM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	PCM	●	●	●	●	0009
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RKE	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	RVM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	TCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2007 MY	TCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	ABS/TCS	●	●	●	●	001E
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	LHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	PCM	●	●	●	●	0009 00C5 00C6
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	RCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2002 MY	RHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	ABS/TCS	●	●	●	●	001E
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	GEM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	LCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	LHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	PCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	RCM	●	●	●	●	0005
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	RHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
ATENZA (JPN) / MAZDA6 (General)	2.0L	LF	2005 MY	TCM	●	●	●	●	00C5
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	4X4	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●	001E
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	LHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	PCM	●	●	●	●	00C6
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	PCM	●	●	●	●	0009 00C6
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	RCM	●	●	●	●	0005
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	RHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2002 MY	TCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	4X4	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●	001E
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	GEM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	IC	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	LCM	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	LHID	●	●	●	●	○
ATENZA (JPN) / MAZDA6 (General)	2.3L	L3	2005 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RCM	●	●	●	●	0005
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RHID	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	RKE	●	●	●	●	0005
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3	2005 MY	TCM	●	●	●	●	00C5
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	4X4	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	ABS/TCS	●	●	●	●	001E
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	GEM	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	IC	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	LCM	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	LHID	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	PCM	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RCM	●	●	●	●	0005
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RHID	●	●	●	●	○
ATENZA(JPN)/MAZDA6 (General)	2.3L	L3 T	2005 MY	RKE	●	●	●	●	0005
ATENZA / MAZDA6	3.7L	CA	Other	4X4	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	ABS	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	ACU	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	AFS	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	BCM/GEM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	BCM/GEM	●	●	●	○	○
ATENZA / MAZDA6	3.7L	CA	Other	BSML	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	BSMR	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	EATC	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	EPS	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	FFH	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	IC	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	ICCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	LCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	MPM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	RCM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	RKE	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	RVM	●	●	●	●	○
ATENZA / MAZDA6	3.7L	CA	Other	TCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ATENZA / MAZDA6	3. 7L	CA	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	3. 7L	CA	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	4X4	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	ABS	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	ACU	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	AFS	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	BCM/GEM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	BCM/GEM	●	●	●	○	○
ATENZA / MAZDA6	2. 5L	L5	Other	BSML	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	BSMR	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	EATC	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	EPS	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	FFH	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	IC	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	ICCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	LCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	MPM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	RCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	RKE	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	RVM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2. 5L	L5	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	4X4	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	ABS	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	ACU	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	AFS	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	BCM/GEM	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	BCM/GEM	●	●	●	○	○
ATENZA / MAZDA6	1. 8L	L8	Other	BSML	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	BSMR	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	EATC	●	●	●	●	○
ATENZA / MAZDA6	1. 8L	L8	Other	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ATENZA / MAZDA6	1.8L	L8	Other	FFH	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	IC	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	ICCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	LCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	MPM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	RCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	RKE	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	RVM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	1.8L	L8	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	4X4	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	ABS	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	ACU	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	AFS	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	BCM/GEM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	BCM/GEM	●	●	●	○	○
ATENZA / MAZDA6	2.0L	LF	Other	BSML	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	BSMR	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	EATC	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	EPS	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	FFH	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	IC	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	ICCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	LCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	MPM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	RCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	RKE	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	RVM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	TCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ATENZA / MAZDA6	2.0L	LF	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2.0L	LF	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	4X4	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	ABS	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	ACU	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	AFS	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	BCM/GEM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	BCM/GEM	●	●	●	○	○
ATENZA / MAZDA6	2.2L	R2 T	Other	BSML	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	BSMR	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	EATC	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	EPS	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	FFH	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	IC	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	ICCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	LCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	MPM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	PCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	RCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	RKE	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	RVM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	TCM	●	●	●	●	○
ATENZA / MAZDA6	2.2L	R2 T	Other	TCM	●	●	●	●	○
ATENZA AMC MZ	2.0L	PE	Other	BSML	●	●	●	●	○
ATENZA AMC MZ	2.0L	PE	Other	BSMR	●	●	●	○	○
ATENZA AMC MZ	2.0L	PE	Other	RVM	●	●	●	○	○
ATENZA AMC MZ	2.2L	SH	Other	BSML	●	●	●	●	○
ATENZA AMC MZ	2.2L	SH	Other	BSMR	●	●	●	○	○
ATENZA AMC MZ	2.2L	SH	Other	RVM	●	●	●	○	○
ATENZA AMC MZ	2.5L	PY	Other	BSML	●	●	●	●	○
ATENZA AMC MZ	2.5L	PY	Other	BSMR	●	●	●	○	○
ATENZA AMC MZ	2.5L	PY	Other	RVM	●	●	●	○	○
AXELA / MAZDA3	2.3L	L3 T	Other	4X4	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3	2.3L	L3 T	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.3L	L3 T	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.3L	L3 T	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	IC	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	MID#1	●	●	●	○	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	2.3L	L3 T	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.3L	L3 T	Other	TCM	●	●	●	○	○
AXELA / MAZDA3	2.5L	L5	Other	4X4	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.5L	L5	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.5L	L5	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3	2.5L	L5	Other	IC	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	MID#1	●	●	●	○	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	2.5L	L5	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.5L	L5	Other	TCM	●	●	●	○	○
AXELA / MAZDA3	2.0L	LF	Other	4X4	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.0L	LF	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.0L	LF	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	IC	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	MID#1	●	●	●	○	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3	2.0L	LF	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	2.0L	LF	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	LF	Other	TCM	●	●	●	○	○
AXELA / MAZDA3	2.0L	PE	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.0L	PE	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.0L	PE	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	IC	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	2.0L	PE	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	2.0L	PE	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	4X4	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.2L	R2 T	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	2.2L	R2 T	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	FFH	●	●	●	●	○
AXELA / MAZDA3	2.2L	R2 T	Other	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3	1.6L	Y6	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	1.6L	Y6	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Y6	Other	TCM	●	●	●	○	○
AXELA / MAZDA3	1.6L	Z6	Other	4X4	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	1.6L	Z6	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	1.6L	Z6	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	IC	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	MID#1	●	●	●	○	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	1.6L	Z6	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.6L	Z6	Other	TCM	●	●	●	○	○
AXELA / MAZDA3	1.5L	ZY	Other	4X4	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3	1.5L	ZY	Other	ABS	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	ACU	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	AFS	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	1.5L	ZY	Other	BCM/GEM	●	●	●	○	○
AXELA / MAZDA3	1.5L	ZY	Other	BSML	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	BSMR	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	EATC	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	EPS	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	IC	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	LCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	MID#1	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	MID#1	●	●	●	○	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	PCM	●	●	●	○	○
AXELA / MAZDA3	1.5L	ZY	Other	RCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	RKE	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	RVM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	TCM	●	●	●	●	○
AXELA / MAZDA3	1.5L	ZY	Other	TCM	●	●	●	○	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	EPS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	PCM	●	●	●	●	00C5
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2003 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	PCM	●	●	●	●	00C5
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	1.5L	ZY	2006 MY	RKE	●	●	●	●	0005
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	EPS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	PCM	●	●	●	●	00C5 00C6
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2003 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	4X4	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	EPS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	PCM	●	●	●	●	00C5
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●	0005
AXELA / MAZDA3 (Japan / General Specs.)	2.0L	LF	2006 MY	TCM	●	●	●	●	00C5
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	EPS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	PCM	●	●	●	●	00C6
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2003 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	EPS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	PCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	RKE	●	●	●	●	0005
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3	2006 MY	TCM	●	●	●	●	00C5
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	ABS	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	EATC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	GEM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	IC	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	PCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	RCM	●	●	●	●	○
AXELA / MAZDA3 (Japan / General Specs.)	2.3L	L3 T	2006 MY	RKE	●	●	●	●	0005
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1999 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1999 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1999 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	Other	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	Other	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	Other	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	2000 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	F6A-T	1998 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1999 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	1998 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2000 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2001 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2002 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A	2005 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1999 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1999 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1999 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	Other	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	Other	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	Other	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	Other	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2000 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2000 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2000 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	RCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	1998 MY	TCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2001 MY	ABS	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2001 MY	PCM	●	●	●	●	○
AZ WAGON(MD/MJ)/SPIANO (HF)	660cc	K6A T	2001 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	ABS	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	PCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	1999 MY	TCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	ABS	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	PCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2002 MY	TCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2003 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AZ OFFROAD	660cc	K6A T	2003 MY	PCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2003 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2003 MY	TCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	ABS	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	PCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2004 MY	TCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2008 MY	ABS	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2008 MY	PCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2008 MY	RCM	●	●	●	●	○
AZ OFFROAD	660cc	K6A T	2008 MY	TCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	ABS	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2003 MY	RCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	ABS	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2005 MY	RCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	ABS	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A	2006 MY	RCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2003 MY	ABS	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2003 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2003 MY	RCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2005 MY	ABS	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2005 MY	PCM	●	●	●	●	○
AZ-WAGON (MJ)	660cc	K6A T	2005 MY	RCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A T	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A T	Other	BCM#1	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	EATC	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	EPS	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	PCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
AZ-WAGON / CAROL	660cc	K6A T	Other	TCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A T	Other	TCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A	Other	BCM#1	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	EATC	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	EPS	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	PCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	RCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	TCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A	Other	TCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A S	Other	ABS	●	●	●	○	○
AZ-WAGON / CAROL	660cc	K6A S	Other	BCM#1	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	EATC	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	EPS	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	PCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	RCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	TCM	●	●	●	●	○
AZ-WAGON / CAROL	660cc	K6A S	Other	TCM	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	ABS	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	ABS	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	EATC	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	EPS	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	GEM	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	IC	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	LPSDM	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	PCM	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	RCM	●	●	●	●	0005
Biante(Japan)	2. 3L	L3	2008 MY	RKE	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	RPSDM	●	●	●	●	○
Biante(Japan)	2. 3L	L3	2008 MY	TCM	●	●	●	○	○
Biante(Japan)	2. 0L	LF	2008 MY	4X4	●	●	●	●	○
Biante(Japan)	2. 0L	LF	2008 MY	ABS	●	●	●	●	○
Biante(Japan)	2. 0L	LF	2008 MY	ABS	●	●	●	●	○
Biante(Japan)	2. 0L	LF	2008 MY	EATC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Biante(Japan)	2.0L	LF	2008 MY	EPS	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	GEM	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	IC	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	LPSDM	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	PCM	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	RCM	●	●	●	●	0005
Biante(Japan)	2.0L	LF	2008 MY	RKE	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	RPSDM	●	●	●	●	○
Biante(Japan)	2.0L	LF	2008 MY	TCM	●	●	●	○	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	1999 MY	ABS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	1999 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	ABS/TCS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	F8	2002 MY	TCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	2010 MY	ABS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	2010 MY	IC	●	●	●	○	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	2010 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	1.8L	L8	2010 MY	TCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.2L	R2	1999 MY	ABS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.2L	R2	1999 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2003 MY	TCM	●	●	●	●	00C5
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2004 MY	TCM	●	●	●	●	00C5
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	ABS/TCS	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	PCM	●	●	●	●	○
BONGO / BONGO BRAUNY / SPECTRON	2.0L	RF-T	2007 MY	TCM	●	●	●	●	00C5
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1997 MY	ABS	●	●	●	●	○
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1997 MY	PCM	●	●	●	●	○
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1998 MY	ABS	●	●	●	●	○
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1998 MY	PCM	●	●	●	●	○
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1999 MY	ABS	●	●	●	●	○
BONGO BRAUNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	1999 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	ABS/TCS	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	PCM	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.0L	FE	2002 MY	TCM	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.2L	R2	1999 MY	ABS	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.2L	R2	1999 MY	PCM	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.5L	WL	1999 MY	ABS	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2.5L	WL	1999 MY	PCM	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1.8L	F8	1999 MY	ABS	●	●	●	●	○
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1.8L	F8	1999 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	1999 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	1996 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.2L	F2	Other	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1999 MY	ABS	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1999 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.6L	G6	1996 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2001 MY	ABS	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2001 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL	2002 MY	ABS	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 MY	ABS	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2001 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2002 MY	ABS	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2.5L	WL_T	2005 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	2005 MY	PCM	●	●	●	●	○
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 9L	W9	2002 MY	ABS	●	●	●	●	○
BT 50 / Ranger	2. 5L	L5	2012 MY	ABS	●	●	●	●	○
BT 50 / Ranger	2. 5L	L5	2012 MY	PCM	●	●	●	○	○
BT-50 / Ranger	2. 5L	WL-CD	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2. 5L	WL-CD	2007 MY	PCM	●	●	●	●	○
BT-50 / Ranger	2. 5L	WL-CD	2007 MY	RCM	●	●	●	●	○
BT-50 / Ranger	2. 5L	WL-CD	2007 MY	TCM	●	●	●	●	00C5
BT-50 / Ranger	2. 5L	WL	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2. 5L	WL	2007 MY	PCM	●	●	●	●	○
BT-50 / Ranger	2. 5L	WL	2007 MY	RCM	●	●	●	●	○
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	PCM	●	●	●	●	○
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	RCM	●	●	●	●	○
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	TCM	●	●	●	●	00C5
BT-50 / Ranger	2. 2L	F2	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2. 2L	F2	2007 MY	PCM	●	●	●	●	○
BT-50 / Ranger	2. 2L	F2	2007 MY	RCM	●	●	●	●	○
BT-50 / Ranger	2. 6L	G6	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	2. 6L	G6	2007 MY	PCM	●	●	●	●	○
BT-50 / Ranger	2. 6L	G6	2007 MY	RCM	●	●	●	●	○
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	ABS/TCS	●	●	●	●	○
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	ESOF	●	●	●	●	○
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	PCM	●	●	●	●	0023
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	RCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	1. 8L	FP	1997 MY	PCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	1. 8L	FP	1999 MY	ABS	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	1. 8L	FP	1999 MY	PCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	2. 0L	FS	1997 MY	PCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	2. 0L	FS	1999 MY	ABS	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	2. 0L	FS	1999 MY	PCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	2. 0L	RF	1997 MY	PCM	●	●	●	●	○
CAPELLA / CAPELLA W / TELSTAR / TELSTAR	2. 5L	KL	1999 MY	ABS	●	●	●	●	○
CAROL	660cc	K6A	1999 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CAROL	660cc	K6A	1999 MY	PCM	●	●	●	●	○
CAROL	660cc	K6A	1999 MY	RCM	●	●	●	●	○
CAROL	660cc	K6A	1999 MY	TCM	●	●	●	●	○
CAROL	660cc	K6A	Other	ABS	●	●	●	●	○
CAROL	660cc	K6A	Other	PCM	●	●	●	●	○
CAROL	660cc	K6A	Other	PCM	●	●	●	●	○
CAROL	660cc	K6A	Other	RCM	●	●	●	●	○
CAROL	660cc	K6A	Other	TCM	●	●	●	●	○
CAROL	660cc	K6A	1998 MY	ABS	●	●	●	●	○
CAROL	660cc	K6A	1998 MY	PCM	●	●	●	●	○
CAROL	660cc	K6A	1998 MY	RCM	●	●	●	●	○
CAROL	660cc	K6A	1998 MY	TCM	●	●	●	●	○
CAROL	660cc	K6A	2000 MY	ABS	●	●	●	●	○
CAROL	660cc	K6A	2000 MY	PCM	●	●	●	●	○
CAROL	660cc	K6A	2000 MY	RCM	●	●	●	●	○
CAROL	660cc	K6A	2000 MY	TCM	●	●	●	●	○
CAROL	660cc	K6A	2001 MY	ABS	●	●	●	●	○
CAROL	660cc	K6A	2001 MY	PCM	●	●	●	●	○
CAROL	660cc	K6A	2001 MY	RCM	●	●	●	●	○
CAROL	660cc	K6A	2001 MY	TCM	●	●	●	●	○
CAROL	660cc	K6A	2002 MY	ABS	●	●	●	●	○
CAROL	660cc	K6A	2002 MY	PCM	●	●	●	●	○
CAROL	660cc	K6A	2002 MY	RCM	●	●	●	●	○
CAROL	660cc	F6A	Other	ABS	●	●	●	●	○
CAROL	660cc	F6A	Other	PCM	●	●	●	●	○
CAROL	660cc	F6A	Other	PCM	●	●	●	●	○
CAROL	660cc	F6A	Other	RCM	●	●	●	●	○
CAROL	660cc	F6A	1998 MY	ABS	●	●	●	●	○
CAROL	660cc	F6A	1998 MY	PCM	●	●	●	●	○
CAROL	660cc	F6A	1998 MY	PCM	●	●	●	●	○
CAROL	660cc	F6A	1998 MY	RCM	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	Other	ABS	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	Other	RCM	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2003 MY	ABS	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2003 MY	PCM	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2003 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CAROL (2003 / 9 -)	660cc	K6A	2004 MY	ABS	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2004 MY	PCM	●	●	●	●	○
CAROL (2003 / 9 -)	660cc	K6A	2004 MY	RCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	ABS	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	PCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	PCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2004 MY	RCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	ABS	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	PCM	●	●	●	●	○
CAROL (HB24S)	660cc	K6A	2005 MY	RCM	●	●	●	●	○
CX 7	2. 5L	PY	Other	BSML	●	●	●	●	○
CX 7	2. 5L	PY	Other	BSMR	●	●	●	○	○
CX 7	2. 5L	PY	Other	RVM	●	●	●	○	○
CX 7	2. 2L	SH	Other	BSML	●	●	●	●	○
CX 7	2. 2L	SH	Other	BSMR	●	●	●	○	○
CX 7	2. 2L	SH	Other	RVM	●	●	●	○	○
CX 7	2. 0L	PE	Other	BSML	●	●	●	●	○
CX 7	2. 0L	PE	Other	BSMR	●	●	●	○	○
CX 7	2. 0L	PE	Other	RVM	●	●	●	○	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	4X4	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	ABS	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	AM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	EATC	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	GEM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	IC	●	●	●	●	0005 001A
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	LCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	PCM	●	●	●	●	0037 00C5 00C6
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	RCM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	RKE	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2006 MY	TCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2009 MY	4X4	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2009 MY	ABS	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2009 MY	ACU	●	●	●	●	○
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2009 MY	AM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2. 3L	L3 T	2009 MY	EATC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	GEM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	IC	●	●	●	●	001A
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	LCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	MID#1	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	PCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	RCM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	RKE	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	RVM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.3L	L3 T	2009 MY	TCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	4X4	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	ABS	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	ACU	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	AM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	EATC	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	EPS	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	FFH	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	GEM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	IC	●	●	●	●	001A
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	LCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	MID#1	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	PCM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	RCM	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	RKE	●	●	●	●	0005
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	RVM	●	●	●	●	○
CX-7 (Europe / General Specs.)	2.2L	R2 T	2009 MY	SCR CU	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	4X4	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	ABS	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	AM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	EATC	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	GEM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	IC	●	●	●	●	0005 001A
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	ICCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	LCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	PCM	●	●	●	●	0037 00C5 00C6
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	RCM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	RKE	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-7 (Japan / General Specs.)	2.3L	L3 T	2006 MY	TCM	●	●	●	●	00C5
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	4X4	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	ABS	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	ACU	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	AM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	EATC	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	GEM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	IC	●	●	●	●	001A
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	ICCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	LCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	MID#1	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	PCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	RCM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	RKE	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	RVM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.3L	L3 T	2009 MY	TCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	4X4	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ABS	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ACU	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	AM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	EATC	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	GEM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	IC	●	●	●	●	001A
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	ICCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	LCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	MID#1	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	PCM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RCM	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RKE	●	●	●	●	0005
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	RVM	●	●	●	●	○
CX-7 (Japan / General Specs.)	2.5L	L5	2009 MY	TCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	4X4	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	ABS	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	AM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	EATC	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	GEM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	IC	●	●	●	●	0005 001A
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	PCM	●	●	●	●	0037 00C5 00C6
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	RCM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	RKE	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2007 MY	TCM	●	●	●	●	00C5
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	4X4	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	ABS	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	AM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	EATC	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	GEM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	IC	●	●	●	●	0005 001A
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	PCM	●	●	●	●	0037 00C5 00C6
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	RCM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	RKE	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2008 MY	TCM	●	●	●	●	00C5
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	4X4	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	ABS	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	AM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	EATC	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	GEM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	IC	●	●	●	●	0005 001A
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	PCM	●	●	●	●	0037 00C5 00C6
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	RCM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	RKE	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2009 MY	TCM	●	●	●	●	00C5
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	4X4	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	ABS	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	ACU	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	AM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	BSML	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	BSMR	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	EATC	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	GEM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	IC	●	●	●	●	001A
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	LCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	MID#1	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	PCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	RCM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	RKE	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.3L	L3 T	2010 MY	TCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	4X4	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ABS	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	ACU	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	AM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSML	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	BSMR	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	EATC	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	GEM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	IC	●	●	●	●	001A
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	LCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	MID#1	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	PCM	●	●	●	●	○
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RCM	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	RKE	●	●	●	●	0005
CX-7 (North America / General Specs.)	2.5L	L5	2010 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	Other	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.5L	CY	Other	LCM	●	●	○	○	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	PCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	Other	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	Other	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	Other	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LCM	●	●	○	○	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	PCM	●	●	●	●	0037
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.5L	CY	2007 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSML	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	BSMR	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LCM	●	●	○	○	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	PCM	●	●	●	●	0037
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2008 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSML	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	BSMR	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	PCM	●	●	●	●	0037
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2009 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	ACU	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSML	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	BSMR	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	DSM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	PCM	●	●	●	●	0037
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2010 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	4X4	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ABS	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	ACU	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	AM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSML	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	BSMR	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	DSM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	GEM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	IC	●	●	●	●	0005 001A
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	LTM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	PCM	●	●	●	○	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RCM	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	RKE	●	●	●	●	0005
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	TCM	●	●	●	●	○
CX-9 (North America / General Specs.)	3.7L	CA	2011 MY	VSM	●	●	●	○	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	4X4	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.3L	ZJ	2007 MY	TCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (General)	1.5L	ZY	2007 MY	TCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	Other	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	Other	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	Other	IC	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	Other	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	Other	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	IC	●	●	●	●	0009
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2002 MY	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2004 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2004 MY	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.3L	ZJ	2004 MY	IC	●	●	●	●	0009

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2004 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2004 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2004 MY	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	EPS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	IC	●	●	●	●	0009
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	LCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 3L	ZJ	2005 MY	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	Other	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	Other	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	Other	IC	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	Other	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	Other	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1. 5L	ZY	2002 MY	ABS/TCS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2002 MY	IC	●	●	●	●	0009
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2002 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2002 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2002 MY	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	IC	●	●	●	●	0009
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2004 MY	RKE	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	4X4	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	ABS/TCS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	EPS	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	IC	●	●	●	●	0009
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	LCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	PCM	●	●	●	●	00C5 00C6
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	RCM	●	●	●	●	○
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	1.5L	ZY	2005 MY	RKE	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	ABS	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	PCM	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	2000 MY	PCM	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	1998 MY	PCM	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	1996 MY	ABS	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.3L	B3	1996 MY	PCM	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	ABS	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	ABS/TCS	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.5L	B5	2000 MY	PCM	●	●	●	●	○
DEMIO / 121 DEMIO / 121	1.5L	B5	1996 MY	ABS	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	Other	PCM	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1996 MY	ABS	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1996 MY	PCM	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1999 MY	ABS	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	1999 MY	PCM	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000 MY	PCM	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.3L	B3	2000 MY	PCM	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.5L	B5	1996 MY	ABS	●	●	●	●	○
DEMIO / FESTIVA MINI WAGON	1.5L	B5	1999 MY	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	4X4	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	EATC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RCM	●	●	●	○	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RKE	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	TCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	ZJ	Other	VSM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	4X4	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	EATC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	RCM	●	●	●	○	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	TCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.3L	P3	Other	VSM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	4X4	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	EATC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RCM	●	●	●	○	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RKE	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	TCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.5L	ZY	Other	VSM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	4X4	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	ABS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	BCM/GEM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	EATC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	EPS	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	IC	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	PCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RCM	●	●	●	○	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	RKE	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	TCM	●	●	●	●	○
DEMIO (JPN) / MAZDA2 (OTHER)	1.6L	Y6	Other	VSM	●	●	●	●	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	ABS	●	●	●	●	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	IC	●	●	●	●	○
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	PCM	●	●	●	●	0009 00C5 00C6
Escape / Tribute (2006/4 -)	2.3L	L3	2006 MY	RCM	●	●	●	●	○
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	ABS	●	●	●	●	○
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	GEM	●	●	●	●	○
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	IC	●	●	●	●	○
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	PCM	●	●	●	●	0009 00C5
Escape / Tribute (2006/3)	2.3L	L3	2003 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	GEM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape / Tribute / Maverick	2.0L	Zetec	2001 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	GEM	●	●	●	●	000A
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	2.0L	Zetec	2002 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	GEM	●	●	●	●	000A
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	2.0L	Zetec	2003 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	GEM	●	●	●	●	000A
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	2.0L	Zetec	2004 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2001 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2001 MY	GEM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2001 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2001 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	3.0L	4V	2001 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2002 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2002 MY	GEM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2002 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2002 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	3.0L	4V	2002 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2003 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2003 MY	GEM	●	●	●	●	000A
Escape / Tribute / Maverick	3.0L	4V	2003 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2003 MY	PCM	●	●	●	●	0009 0010 0023 0028 0031 0033
Escape / Tribute / Maverick	3.0L	4V	2003 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2004 MY	ABS/TCS	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2004 MY	GEM	●	●	●	●	000A
Escape / Tribute / Maverick	3.0L	4V	2004 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2004 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Escape / Tribute / Maverick	3.0L	4V	2004 MY	RCM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2006 MY	4X4	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2006 MY	ABS	●	●	●	●	0005 0008
Escape / Tribute / Maverick	3.0L	4V	2006 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2006 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2006 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2006 MY	IC	●	●	●	●	0005
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2006 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	3.0L	4V	2006 MY	RCM	●	●	●	●	000C
Escape / Tribute / Maverick	3.0L	4V	2007 MY	4X4	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2007 MY	ABS	●	●	●	●	0008
Escape / Tribute / Maverick	3.0L	4V	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	3.0L	4V	2007 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	3.0L	4V	2007 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	3.0L	4V	2007 MY	RCM	●	●	●	●	000C
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	4X4	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	ABS	●	●	●	●	0008
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●	000A 000F

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 MY	RCM	●	●	●	●	000C
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	4X4	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	ABS	●	●	●	●	0008
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●	000A 000F
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	IC	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PAM	●	●	●	●	○
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033 00C5
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2007 MY	RCM	●	●	●	●	000C
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	ABS	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	ACM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	APIM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	BCM#1	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DDM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DSM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DSP	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	FCDIM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	FCIM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	GPSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	HCM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	HVAC	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	IPC	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	IPM-B	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	OCSM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PAM	●	●	○	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PCM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PDM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PSCM	●	●	●	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RCM	●	●	●	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RFA	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RGTM	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SASM	●	●	●	○	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SOD-L	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SOD-R	●	●	●	●	○
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	TRM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	ABS	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	ACM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	APIM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	BCM#1	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DDM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DSM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	DSP	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	FCDIM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	FCIM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	GPSM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	HCM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	HVAC	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	IPC	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	IPM-B	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	OCSM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PAM	●	●	○	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PCM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PDM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	PSCM	●	●	●	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RCM	●	●	●	○	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RFA	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	RGTM	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SASM	●	●	●	○	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SOD-L	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	SOD-R	●	●	●	●	○
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 MY	TRM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	ABS	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	ACM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	APIM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	BCM#1	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	DDM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	DSM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	DSP	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	FCDIM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	FCIM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	GPSM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	HCM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	HVAC	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	IPC	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	IPM-B	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	OCSM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	PAM	●	●	○	○	○
Escape/Kuga	2.5L	IVCT	2013 MY	PCM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	PDM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	PSCM	●	●	●	○	○
Escape/Kuga	2.5L	IVCT	2013 MY	RCM	●	●	●	○	○
Escape/Kuga	2.5L	IVCT	2013 MY	RFA	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	RGTM	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	SASM	●	●	●	○	○
Escape/Kuga	2.5L	IVCT	2013 MY	SOD-L	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape/Kuga	2.5L	IVCT	2013 MY	SOD-R	●	●	●	●	○
Escape/Kuga	2.5L	IVCT	2013 MY	TRM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ABS	●	●	●	●	0005 0012
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ACM	●	●	●	●	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	ACM	●	●	●	●	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	BCM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	FDIM	●	●	●	●	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	GEM / SJB	●	●	●	●	000A 000F
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	IC	●	●	●	●	0005 0009
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PAM	●	●	●	●	○
Escape_/Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PCM	●	●	●	●	0010 0023 0028 0031 0033 00C5
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	RCM	●	●	●	●	0005
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	HEV / ATKINSON 4V	2008 MY	TCM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ABS	●	●	●	●	0005 0008 0012
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB	●	●	●	●	000A 000F
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	IC	●	●	●	●	0005 0009
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PAM	●	●	●	●	○
Escape_/Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	RCM	●	●	●	●	0005
Escape /Tribute / Mariner	2.3L	DURATEC-HE / I4	2008 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ABS	●	●	●	●	0005 0008 0012
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	GEM / SJB	●	●	●	●	000A 000F
Escape /Tribute / Mariner	3.0L	4V	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	IC	●	●	●	●	0009
Escape /Tribute / Mariner	3.0L	4V	2008 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PAM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	3.0L	4V	2008 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	3.0L	4V	2008 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2008 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ABS	●	●	●	●	0005 0008 0012
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2009 MY	FDIM	●	●	●	●	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	GEM / SJB	●	●	●	●	000A 000F
Escape /Tribute / Mariner	3.0L	4V	2009 MY	HVAC	●	●	●	●	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	HVAC	●	●	●	●	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	IC	●	●	●	●	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PAM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape_/Tribute / Mariner	3.0L	4V	2009 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033 00C5
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	3.0L	4V	2009 MY	RCM	●	●	●	●	000C
Escape /Tribute / Mariner	3.0L	4V	2009 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	GPSM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	3.0L	4V	2010 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	3.0L	4V	2011 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	3.0L	4V	2011 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	3.0L	4V	2012 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	BCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	GEM / SJB	●	●	●	●	000A 000F
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	HVAC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	IC	●	●	●	●	0009
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PAM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PCM	●	●	●	●	0023 0025
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	RCM	●	●	●	●	000C
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 MY	TCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ABS	●	●	●	●	0005
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACCM#2	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	BCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	FDIM	●	●	●	●	0005
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GEM / SJB	●	●	●	●	000A 000F 0042
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	GPSM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	IC	●	●	●	●	0005 0009
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	OCSM	●	●	●	●	000C
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PAM	●	●	●	○	○
Escape_/Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	PSCM	●	●	○	○	0005
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	RCM	●	●	●	●	0005 000C
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 MY	TCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACCM#2	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACM	●	●	●	○	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	BCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2011 MY	TCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACCM#2	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	BCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PAM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2012 MY	TCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PAM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 MY	SDARS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	ACM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	APIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	GPSM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	OCSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2011 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GEM / SJB	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PCM	●	●	●	●	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	2.5L	DURATEC-HE / I4	2012 MY	RCM	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	4X4	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	ABS	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	ACM	●	●	●	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	APIM	●	●	●	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	FCIM	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	FDIM	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	GEM / SJB	●	●	●	●	0042
Escape /Tribute / Mariner	Other	Other	2012 MY	GPSM	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	HVAC	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	IC	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	OCSM	●	●	●	●	○
Escape /Tribute / Mariner	Other	Other	2012 MY	PAM	●	●	●	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	PSCM	●	●	○	○	○
Escape /Tribute / Mariner	Other	Other	2012 MY	RCM	●	●	●	●	○
FAMILIA / LASER	1.3L	B3	1998 MY	ABS	●	●	●	●	○
FAMILIA / LASER	1.3L	B3	1998 MY	PCM	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	1998 MY	ABS	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	1998 MY	PCM	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2000 MY	ABS	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2000 MY	ABS/TCS	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2000 MY	PCM	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2000 MY	PCM	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2002 MY	ABS/TCS	●	●	●	●	○
FAMILIA / LASER	1.5L	ZL	2002 MY	PCM	●	●	●	●	○
FAMILIA / LASER	1.8L	FP	1998 MY	ABS	●	●	●	●	○
FAMILIA / LASER	1.8L	FP	1998 MY	PCM	●	●	●	●	○
FAMILIA / LASER	2.0L	RF	1998 MY	ABS	●	●	●	●	○
FAMILIA / LASER	2.0L	RF	1998 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
FAMILIA / LASER	2.0L	FS	1999 MY	ABS	●	●	●	●	○
FAMILIA / LASER	2.0L	FS	1999 MY	PCM	●	●	●	●	○
FAMILIA / LASER	2.0L	FS	2000 MY	ABS	●	●	●	●	○
FAMILIA / LASER	2.0L	FS	2000 MY	PCM	●	●	●	●	○
FAMILIA / LASER	2.0L	FS	2002 MY	ABS/TCS	●	●	●	●	○
FAMILIA / LASER	2.0L	FS	2002 MY	PCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	ABS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	EPS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	GEM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IC	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	IPDM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	PCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.2L	CR12	2007 MY	RCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	ABS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	EPS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	GEM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IC	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	IPDM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	PCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.5L	HR15	2007 MY	RCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	ABS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	EPS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	GEM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IC	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	IPDM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	PCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.8L	MR18	2007 MY	RCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	ABS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	EPS	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	GEM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IC	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	IPDM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	PCM	●	●	●	●	○
FAMILIA VAN (BV*Y12)	1.6L	HR16	2007 MY	RCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.3L	QG13	1999 MY	PCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.3L	QG13	2002 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
FAMILIA WAGON/VAN (B*Y11 500000)	1.3L	QG13	2002 MY	PCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.5L	QG15	1999 MY	PCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.5L	QG15	2002 MY	ABS	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.5L	QG15	2002 MY	PCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.8L	QG18	1999 MY	PCM	●	●	●	●	○
FAMILIA WAGON/VAN (B*Y11 500000)	1.8L	QG18	2002 MY	PCM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	PCM	●	●	●	●	0009 0023 0025
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001 MY	PCM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	PCM	●	●	●	●	0009 0023 0025
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996.75 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1996.75 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996. 75 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996. 75 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997. 5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997. 5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997. 5 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1997. 5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1997. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 25L	Zetec-SE	1997. 5 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1997.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1997.5 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1998.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1998.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1998.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1998.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1998.5 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	GEM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.25L	Zetec-SE	1999.5 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	2000 MY	PCM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	GEM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	Zetec Rocam	1999.75 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996.75 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996.75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996.75 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1996.75 MY	PCM	●	●	●	●	0025
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1997.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1997.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1997.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1997.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.0L	HCS	1997.5 MY	PCM	●	●	●	●	0025
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1999 MY	PCM	●	●	●	●	0025
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	PATS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	PCM	○	○	●	○	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	PATS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	PCM	○	○	●	○	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	FIP	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	GEM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PATS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	PCM	●	●	●	●	0009
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	PCM	●	●	●	●	0023 0025

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996. 75 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996. 75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996. 75 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996. 75 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1996. 75 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1997 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1997 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1997 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1997 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1997 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1997. 5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1997. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1997. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1997. 5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1997. 5 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	19985 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	19985 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	19985 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	19985 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	19985 MY	PCM	●	●	●	●	0023 0025
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999. 5 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999. 5 MY	CSM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999. 5 MY	CSM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ECS	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	GEM	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	HEC	●	●	●	●	○
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	PCM	●	●	●	●	0009 0023 0025
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ABS/TCS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	CSM	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ECS	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	HEC	●	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	PCM	●	●	●	●	○
FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	1999 MY	PCM	●	●	●	●	○
FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	1997 MY	PCM	●	●	●	●	○
FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	2002 MY	PCM	●	●	●	●	○
FRIENDEE / FRED A / BONGO FRIENDEE	2.0L	FE	2002 MY	TCM	●	●	●	●	○
FRIENDEE / FRED A / BONGO FRIENDEE	2.5L	WL T	1999 MY	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1999 MY	ABS	●	●	●	●	○
LAPUTA	660cc	F6A-T	1999 MY	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1999 MY	RCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	Other	ABS	●	●	●	●	○
LAPUTA	660cc	F6A-T	Other	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	Other	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	Other	RCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	ABS	●	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	RCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	1998 MY	TCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	2001 MY	ABS	●	●	●	●	○
LAPUTA	660cc	F6A-T	2001 MY	PCM	●	●	●	●	○
LAPUTA	660cc	F6A-T	2001 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A T	1999 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A T	1999 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
LAPUTA	660cc	K6A T	1999 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A T	Other	ABS	●	●	●	●	○
LAPUTA	660cc	K6A T	Other	PCM	●	●	●	●	○
LAPUTA	660cc	K6A T	Other	PCM	●	●	●	●	○
LAPUTA	660cc	K6A T	Other	RCM	●	●	●	●	○
LAPUTA	660cc	K6A T	2001 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A T	2001 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A T	2001 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A_T	2001.5 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A_T	2001.5 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A_T	2001.5 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A	2000 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A	2000 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	2000 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A	2001 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A	2001 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	2001 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A	Other	ABS	●	●	●	●	○
LAPUTA	660cc	K6A	Other	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	Other	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	Other	RCM	●	●	●	●	○
LAPUTA	660cc	K6A	2001.5 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A	2001.5 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	2001.5 MY	RCM	●	●	●	●	○
LAPUTA	660cc	K6A	2002 MY	ABS	●	●	●	●	○
LAPUTA	660cc	K6A	2002 MY	PCM	●	●	●	●	○
LAPUTA	660cc	K6A	2002 MY	RCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	Other	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	Other	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
LASER / 323 / TIERRA	1.3L	B3	2000 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	2000 MY	ABS/TCS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	1998 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	1996 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	1996 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	2001 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.3L	B3	2001 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	Other	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	ZL	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	ZL	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	ZL	1998 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	ZL	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	Z5	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	Z5	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	Z5	1996 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.5L	Z5	1996 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	Other	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	1998 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	ABS/TCS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	ZM	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	B6	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	B6	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	B6	1996 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.6L	B6	1996 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	Other	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP	2000 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
LASER / 323 / TIERRA	1.8L	FP	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP	1998 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	FP	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	BP	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	BP	Other	PCM	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	BP	1996 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	1.8L	BP	1996 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF	1998 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF	Other	ABS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF-T	1998 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF-T	2000 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	RF-T	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	FS	2000 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	FS	2000 MY	PCM	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	FS	2001 MY	ABS	●	●	●	●	○
LASER / 323 / TIERRA	2.0L	FS	2001 MY	PCM	●	●	●	●	○
MARVIE	2.5L	G5	1996 MY	PCM	●	●	●	●	○
MAZDA 929	3.0L	JE	1997 MY	PCM	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	ABS	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	EPS	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	IC	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	PCM	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	RCM	●	●	●	●	○
MAZDA2 (China)	1.3L	ZJ	2007 MY	RKE	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	ABS	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	EPS	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	IC	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	PCM	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	RCM	●	●	●	●	○
MAZDA2 (China)	1.5L	ZY	2007 MY	RKE	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	IC	●	●	●	●	0009

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.25L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2002 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZI	2006 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2002 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.4L	MZ CD DI	2006 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	IC	●	●	●	●	0009

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2002 MY	TCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	ABS/TCS	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	IC	●	●	●	●	0009
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	PCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (EURO STG3/4 Specs)	1.6L	MZI	2006 MY	RCM	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	ABS	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	EPS	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	IC	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	PCM	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RCM	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	RKE	●	●	●	●	○
MAZDA2 (Europe)	1.3L	ZJ	2007 MY	VSM	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	ABS	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	EPS	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	IC	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	PCM	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RCM	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	RKE	●	●	●	●	○
MAZDA2 (Europe)	1.5L	ZY	2007 MY	VSM	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	ABS	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	EPS	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	IC	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	PCM	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RCM	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	RKE	●	●	●	●	○
MAZDA2 (Europe)	1.4L	Y4	2007 MY	VSM	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	ABS	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	BCM/GEM	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA2 (Europe)	1.6L	Y6	2008 MY	IC	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	PCM	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RCM	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	RKE	●	●	●	●	○
MAZDA2 (Europe)	1.6L	Y6	2008 MY	VSM	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	ABS	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	EATC	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	EPS	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	GEM	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	IC	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (China / General)	2.0L	LF	2007 MY	RCM	●	●	●	●	○
MAZDA3 (China / General)	2.0L	LF	2007 MY	RKE	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	ABS	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	EATC	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	GEM	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	IC	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (China / General)	1.6L	Z6	2007 MY	RCM	●	●	●	●	○
MAZDA3 (China / General)	1.6L	Z6	2007 MY	RKE	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2003 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Z6	2006 MY	RKE	●	●	●	●	0005
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	FACM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	PCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2003 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	EPS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	FACM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	PCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.6L	Y6	2006 MY	RKE	●	●	●	●	0005
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	EPS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	PCM	●	●	●	●	00C5
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2003 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	EPS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	PCM	●	●	●	●	00C5
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	LF	2006 MY	RKE	●	●	●	●	0005
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	FFH	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	PCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (EURO STG3/4/5 and General	2.0L	RF-T	2006 MY	RKE	●	●	●	●	0005
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2003 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	1.3L	ZJ	2006 MY	RKE	●	●	●	●	0005
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	EPS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	PCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2003 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	ABS	●	●	●	●	001E
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	EPS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	PCM	●	●	●	●	0009
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3	2006 MY	RKE	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	ABS	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	EATC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	GEM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	IC	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	PCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	RCM	●	●	●	●	○
MAZDA3 (EURO STG3/4/5 and General	2.3L	L3 T	2006 MY	RKE	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (North America / General)	2.3L	L3	2004 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	PCM	●	●	●	●	00C6
MAZDA3 (North America / General)	2.3L	L3	2004 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2004 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.3L	L3	2005 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2005 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2005 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.3L	L3	2006 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2006 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	RKE	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2006 MY	TCM	●	●	●	●	00C5
MAZDA3 (North America / General)	2.3L	L3	2006 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.3L	L3	2007 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2007 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2007 MY	TCM	●	●	●	●	00C5

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (North America / General)	2.3L	L3	2007 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.3L	L3	2008 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2008 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2008 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2008 MY	TCM	●	●	●	●	00C5
MAZDA3 (North America / General)	2.3L	L3	2008 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.3L	L3	2009 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2009 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.3L	L3	2009 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3	2009 MY	TCM	●	●	●	●	00C5
MAZDA3 (North America / General)	2.3L	L3	2009 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2007 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2008 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.3L	L3 T	2009 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.0L	LF	2004 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	PCM	●	●	●	●	00C6
MAZDA3 (North America / General)	2.0L	LF	2004 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2004 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.0L	LF	2005 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	PCM	●	●	●	●	00C6
MAZDA3 (North America / General)	2.0L	LF	2005 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2005 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.0L	LF	2006 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	EATC	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2006 MY	PCM	●	●	●	●	00C5
MAZDA3 (North America / General)	2.0L	LF	2006 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	RKE	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2006 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	2.0L	LF	2007 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA3 (North America / General)	2.0L	LF	2007 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2007 MY	PCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2007 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.0L	LF	2008 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2008 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2008 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2008 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	2.0L	LF	2009 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	EPS	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	IC	●	●	●	○	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2009 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	2.0L	LF	2009 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	2.0L	LF	2009 MY	TPM	●	●	●	●	0005 001A
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	RCM	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	RKE	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2006 MY	TPM	●	●	●	●	001A
MAZDA3 (North America / General)	1.6L	Z6	2012 MY	ABS	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2012 MY	GEM	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2012 MY	IC	●	●	●	●	○
MAZDA3 (North America / General)	1.6L	Z6	2012 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	EPS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	PCM	●	●	●	●	00C5
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	ABS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	EPS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	LPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	PCM	●	●	●	●	0037 00C5 00C6
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	RPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	LF	2007 MY	TCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	ABS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	FFH	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	PCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2005 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	ABS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	FFH	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	LPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	PCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	RPSDM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	2.0L	RF-T	2007 MY	TCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	ABS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	EPS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	GEM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	LPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2005 MY	RPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	ABS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	EATC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	EPS	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	IC	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	LPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	PCM	●	●	●	●	0037 00C5 00C6

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RCM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RKE	●	●	●	●	0005
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	RPSDM	●	●	●	●	○
MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX	1.8L	L8	2007 MY	TCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	ABS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EATC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	EPS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	IC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	RCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2006 MY	TPM	●	●	●	●	001A
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	ABS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EATC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	EPS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	GEM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	IC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	RCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2007 MY	TPM	●	●	●	●	001A
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	ABS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EATC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	EPS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	GEM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	IC	●	●	●	○	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	RCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TCM	●	●	●	●	00C5
MAZDA5 (North America Specs.)	2.3L	L3	2008 MY	TPM	●	●	●	●	0005 001A
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	ABS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EATC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	EPS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	GEM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	IC	●	●	●	○	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	RCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TCM	●	●	●	●	00C5
MAZDA5 (North America Specs.)	2.3L	L3	2009 MY	TPM	●	●	●	●	0005 001A
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	ABS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EATC	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	EPS	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	GEM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	IC	●	●	●	○	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	PCM	●	●	●	●	00C5 00C6
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	RCM	●	●	●	●	○
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TCM	●	●	●	●	00C5
MAZDA5 (North America Specs.)	2.3L	L3	2010 MY	TPM	●	●	●	●	0005 001A
MAZDA6 (China)	2.5L	L5	2007 MY	ABS	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	EATC	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	EPS	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	IC	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	LCM	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	PCM	●	●	●	●	0009
MAZDA6 (China)	2.5L	L5	2007 MY	RCM	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	RKE	●	●	●	●	○
MAZDA6 (China)	2.5L	L5	2007 MY	TCM	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	ABS	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	EATC	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	EPS	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	IC	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	LCM	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	PCM	●	●	●	●	0009
MAZDA6 (China)	2.0L	LF	2007 MY	RCM	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	RKE	●	●	●	●	○
MAZDA6 (China)	2.0L	LF	2007 MY	TCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	4X4	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM	●	●	●	●	0009 00C5
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	PCM	●	●	●	●	0009 00C5
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2002 MY	TCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	IC	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	PCM	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2003 MY	TCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	GEM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	PCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	RKE	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.3L	L3	2005 MY	TCM	●	●	●	●	00C5
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	4X4	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	GEM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	LCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	PCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.3L	L3 T	2005 MY	RKE	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	ABS/TCS	●	●	●	●	001E

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	IC	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	PCM	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2002 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	GEM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	PCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	1.8L	L8	2005 MY	RKE	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	PCM	●	●	●	●	0009 00C5
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2002 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	GEM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	PCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	LF	2005 MY	TCM	●	●	●	●	00C5
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	FFH	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	PCM	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	RCM	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2002 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	FFH	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	PCM	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2003 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	FFH	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	PCM	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2004 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	FFH	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	GEM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	IC	●	●	●	●	0009
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	LCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	LHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	PCM	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RCM	●	●	●	●	0005
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RHID	●	●	●	●	○
MAZDA6 (EURO STG3/4 and General)	2.0L	RF-T	2005 MY	RKE	●	●	●	●	0005
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	PCM	●	●	●	●	0009
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	2.5L	L5	2007 MY	TCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	PCM	●	●	●	●	0009
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	1.8L	L8	2007 MY	TCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	PCM	●	●	●	●	0009
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	LF	2007 MY	TCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	FFH	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	PCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	2.0L	RF-T	2007 MY	TCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	BCM/GEM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	FFH	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	PCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2007 MY	TCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	ABS	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	EATC	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	EPS	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	FFH	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	IC	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	LCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	PCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	RCM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	RKE	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	RVM	●	●	●	●	○
MAZDA6 (Europe and General)	2.2L	R2 T	2008 MY	TCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	ABS	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BSML	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	BSMR	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	EATC	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	IC	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	LCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	PCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	RCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	RKE	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2009 MY	TCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	ABS	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BSML	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	BSMR	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	EATC	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	IC	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	LCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	PCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	RCM	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	RKE	●	●	●	●	○
MAZDA6 (Middle East / General)	2.5L	L5	2010 MY	TCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	ABS	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BSML	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	BSMR	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	EATC	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	IC	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	LCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	PCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	RCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	RKE	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2009 MY	TCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	ABS	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BSML	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	BSMR	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	EATC	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	IC	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	LCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	PCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	RCM	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	RKE	●	●	●	●	○
MAZDA6 (Middle East / General)	3.7L	CA	2010 MY	TCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	ABS	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BSML	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	BSMR	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	EATC	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (North America / General)	2.5L	L5	2009 MY	LCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	PCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	RCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	RKE	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2009 MY	TCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	ABS	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BSML	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	BSMR	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	EATC	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	IC	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	LCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	PCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	RCM	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	RKE	●	●	●	●	○
MAZDA6 (North America / General)	2.5L	L5	2010 MY	TCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	ABS	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BSML	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	BSMR	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	EATC	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	IC	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	LCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	PCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	RCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	RKE	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2009 MY	TCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	ABS	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BCM/GEM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BSML	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	BSMR	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	EATC	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	IC	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	LCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	PCM	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6 (North America / General)	3.7L	CA	2010 MY	RKE	●	●	●	●	○
MAZDA6 (North America / General)	3.7L	CA	2010 MY	TCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	Other	ABS/TCS	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	Other	IC	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	Other	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2003 MY	ABS/TCS	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2003 MY	IC	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2003 MY	PCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2003 MY	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2003 MY	TCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (North America/General)	3.0L	AJ	2004 MY	IC	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2004 MY	PCM	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2004 MY	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2004 MY	TCM	●	●	●	●	00C5
MAZDA6 (North America/General)	3.0L	AJ	2005 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (North America/General)	3.0L	AJ	2005 MY	IC	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2005 MY	PCM	●	●	●	●	0009 0037
MAZDA6 (North America/General)	3.0L	AJ	2005 MY	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2005 MY	TCM	●	●	●	●	00C5
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	GEM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	IC	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	PCM	●	●	●	●	0009 0037
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2006 MY	TCM	●	●	●	●	00C5
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	GEM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	IC	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	PCM	●	●	●	●	0009 0037
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	RCM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2007 MY	TCM	●	●	●	●	00C5
MAZDA6 (North America/General)	3.0L	AJ	2008 MY	ABS/TCS	●	●	●	●	001E
MAZDA6 (North America/General)	3.0L	AJ	2008 MY	GEM	●	●	●	●	○
MAZDA6 (North America/General)	3.0L	AJ	2008 MY	IC	●	●	●	●	0009
MAZDA6 (North America/General)	3.0L	AJ	2008 MY	PCM	●	●	●	●	0009 0037

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6(North America/General)	3.0L	AJ	2008 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	3.0L	AJ	2008 MY	TCM	●	●	●	●	00C5
MAZDA6(North America/General)	3.0L	AJ	2008 MY	TPM	●	●	●	○	0005 001A
MAZDA6(North America/General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	IC	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	PCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2003 MY	TCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2004 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3	2004 MY	IC	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2004 MY	PCM	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2004 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2004 MY	TCM	●	●	●	●	00C5
MAZDA6(North America/General)	2.3L	L3	2005 MY	ABS/TCS	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	IC	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	PCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	PCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2005 MY	TCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	IC	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2006 MY	PCM	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2006 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2006 MY	TCM	●	●	●	●	00C5
MAZDA6(North America/General)	2.3L	L3	2007 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3	2007 MY	GEM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2007 MY	IC	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2007 MY	PCM	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2007 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2007 MY	TCM	●	●	●	●	00C5
MAZDA6(North America/General)	2.3L	L3	2008 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3	2008 MY	GEM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3	2008 MY	IC	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2008 MY	PCM	●	●	●	●	0009
MAZDA6(North America/General)	2.3L	L3	2008 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MAZDA6(North America/General)	2.3L	L3	2008 MY	TCM	●	●	●	●	00C5
MAZDA6(North America/General)	2.3L	L3	2008 MY	TPM	●	●	●	○	0005 001A
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	4X4	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	GEM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	IC	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	PCM	●	●	●	●	00C5 00C6
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2006 MY	RKE	●	●	●	●	0005
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	4X4	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	ABS/TCS	●	●	●	●	001E
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	GEM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	IC	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	PCM	●	●	●	●	00C5 00C6
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	RCM	●	●	●	●	○
MAZDA6(North America/General)	2.3L	L3 T	2007 MY	RKE	●	●	●	●	0005
Millenia	2.5L	KL	1997 MY	PCM	●	●	●	●	○
Millenia	2.5L	KL	1998 MY	PCM	●	●	●	●	○
Millenia	2.5L	KL	1999 MY	PCM	●	●	●	●	○
Millenia	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●	○
Millenia	2.5L	KL	2000 MY	PCM	●	●	●	●	○
Millenia	2.5L	KL	2001 MY	ABS/TCS	●	●	●	●	○
Millenia	2.5L	KL	2001 MY	PCM	●	●	●	●	○
Millenia	2.3L	KJ	1997 MY	PCM	●	●	●	●	○
Millenia	2.3L	KJ	1998 MY	PCM	●	●	●	●	○
Millenia	2.3L	KJ	1999 MY	PCM	●	●	●	●	○
Millenia	2.3L	KJ	2000 MY	ABS/TCS	●	●	●	●	○
Millenia	2.3L	KJ	2000 MY	PCM	●	●	●	●	○
Millenia	2.3L	KJ	2001 MY	ABS/TCS	●	●	●	●	○
Millenia	2.3L	KJ	2001 MY	PCM	●	●	●	●	○
MILLENNIA / EUNOS 800	2.0L	KF	1998 MY	ABS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.0L	KF	2000 MY	ABS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.3L	KJ	1998 MY	ABS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.3L	KJ	2000 MY	ABS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.5L	KL	1998 MY	ABS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.5L	KL	2000 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MILLENNIA / EUNOS 800	2.5L	KL	2002 MY	ABS/TCS	●	●	●	●	○
MILLENNIA / EUNOS 800	2.5L	KL	2002 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.0L	FS	1999 MY	ABS	●	●	●	●	○
MPV (Europe/General)	2.0L	FS	1999 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.0L	FS	2000 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.0L	FS	2000 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2002 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2002 MY	FFH	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2002 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2003 MY	FFH	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2003 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2004 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2004 MY	FFH	●	●	●	●	○
MPV (Europe/General)	2.0L	RF-T	2004 MY	PCM	●	●	●	●	○
MPV (Europe/General)	2.5L	GY	2000 MY	ABS	●	●	●	●	○
MPV (Europe/General)	2.5L	GY	2000 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.5L	GY	2000 MY	PCM	●	●	●	●	00C5 00C6
MPV (Europe/General)	2.5L	GY	2000 MY	PCM	●	●	●	●	00C5 00C6
MPV (Europe/General)	2.5L	GY	1999 MY	ABS	●	●	●	●	○
MPV (Europe/General)	2.5L	GY	1999 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.5L	GY	1999 MY	PCM	●	●	●	●	00C5 00C6
MPV (Europe/General)	2.5L	GY	1999 MY	PCM	●	●	●	●	00C5 00C6
MPV (Europe/General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	2.3L	L3	2002 MY	PCM	●	●	●	●	○
MPV (Europe/General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●	○
MPV (Europe/General)	3.0L	AJ	2002 MY	PCM	●	●	●	●	○
MPV (Europe/General)	3.0L	AJ	2002 MY	TCM	●	●	●	●	○
MPV (JPN/General)	2.0L	FS	1999 MY	ABS	●	●	●	●	○
MPV (JPN/General)	2.0L	FS	1999 MY	PCM	●	●	●	●	○
MPV (JPN/General)	2.5L	GY	1999 MY	ABS	●	●	●	●	○
MPV (JPN/General)	2.5L	GY	1999 MY	PCM	●	●	●	●	00C5 00C6
MPV (JPN/General)	2.3L	L3	2002 MY	ABS/TCS	●	●	●	●	○
MPV (JPN/General)	2.3L	L3	2002 MY	PCM	●	●	●	●	00C5 00C6
MPV (JPN/General)	2.3L	L3	2003 MY	ABS/TCS	●	●	●	●	○
MPV (JPN/General)	2.3L	L3	2003 MY	PCM	●	●	●	●	00C5 00C6

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MPV (JPN/General)	2.3L	L3	2004 MY	ABS/TCS	●	●	●	●	○
MPV (JPN/General)	2.3L	L3	2004 MY	PCM	●	●	●	●	00C5 00C6
MPV (JPN/General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●	○
MPV (JPN/General)	3.0L	AJ	2002 MY	PCM	●	●	●	●	○
MPV (JPN/General)	3.0L	AJ	2002 MY	TCM	●	●	●	●	○
MPV (JPN/General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●	○
MPV (JPN/General)	3.0L	AJ	2004 MY	PCM	●	●	●	●	○
MPV (JPN/General)	3.0L	AJ	2004 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	3.0L	JE	1997 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	JE	1998 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	JE	1999 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2002 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2002 MY	PCM	●	●	●	●	00C5 00C6
MPV (North America / General)	3.0L	AJ	2002 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	3.0L	AJ	2004 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2004 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2004 MY	RCM	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2004 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	3.0L	AJ	2003 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2003 MY	PCM	●	●	●	●	00C5 00C6
MPV (North America / General)	3.0L	AJ	2003 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	3.0L	AJ	2005 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2005 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2005 MY	RCM	●	●	●	●	0005
MPV (North America / General)	3.0L	AJ	2005 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	3.0L	AJ	2006 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2006 MY	PCM	●	●	●	●	○
MPV (North America / General)	3.0L	AJ	2006 MY	RCM	●	●	●	●	0005
MPV (North America / General)	3.0L	AJ	2006 MY	TCM	●	●	●	●	00C5
MPV (North America / General)	2.5L	GY	2000 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	2.5L	GY	2000 MY	PCM	●	●	●	●	00C5 00C6
MPV (North America / General)	2.5L	GY	2001 MY	ABS/TCS	●	●	●	●	○
MPV (North America / General)	2.5L	GY	2001 MY	PCM	●	●	●	●	00C5 00C6
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	4X4	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ABS	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	AM	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	GEM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	HCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	IC	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	ICCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	LTM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	PCM	●	●	●	●	0037
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RKE	●	●	●	●	0005
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	RPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM	●	●	●	○	○
MPV / Mazda8 (JPN/General)	2.3L	L3	2006 MY	TCM	●	●	●	●	00C5
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	4X4	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	ABS	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	AM	●	●	●	●	0005
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	GEM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	HCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	IC	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	ICCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	LTM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	PCM	●	●	●	●	0037
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RKE	●	●	●	●	0005
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	RPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.3L	L3 T	2006 MY	TCM	●	●	●	○	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	ABS	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	AM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	GEM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	HCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	ICCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	LTM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RCM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RKE	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	RPSDM	●	●	●	●	○
MPV / Mazda8 (JPN/General)	2.5L	L5	2012 MY	TCM	●	●	●	●	○
MX 5	1.8L	BP	2000 MY	ABS/TCS	●	●	●	●	○
MX 5	1.8L	BP	2000 MY	PCM	●	●	●	●	○
MX 5	1.6L	B6	2000 MY	ABS/TCS	●	●	●	●	○
MX 5	1.6L	B6	2000 MY	PCM	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	ABS	●	●	●	●	0005
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	IC	●	●	●	●	0005
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	PCM	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RCM	●	●	●	●	0005
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RHT	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	RKE	●	●	●	●	0005
MX-5 (Europe / General Specs.)	1.8L	L8	2005 MY	TCM	●	●	●	●	00C5
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	ABS	●	●	●	●	001E
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	IC	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	PCM	●	●	●	●	0009
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RCM	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RHT	●	●	●	●	○
MX-5 (Europe / General Specs.)	1.8L	L8	2008 MY	RKE	●	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	ABS	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	IC	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	PCM	●	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RCM	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RHT	●	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2005 MY	TCM	●	●	●	●	00C5
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	●	○
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●	0005
MX-5 (Europe / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●	00C5
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	ABS	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RCM	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2006 MY	TCM	●	●	●	●	00C5
MX-5 (North America / General Specs.)	2.0L	LF	Other	ABS	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	Other	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	Other	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	Other	RCM	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	Other	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	Other	TCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	ABS	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RCM	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RHT	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2007 MY	TCM	●	●	●	●	00C5
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●	00C5
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	ABS	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RCM	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RHT	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2009 MY	TCM	●	●	●	●	00C5
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	ABS	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	IC	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	PCM	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RCM	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RHT	●	●	●	●	○
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	RKE	●	●	●	●	0005
MX-5 (North America / General Specs.)	2.0L	LF	2010 MY	TCM	●	●	●	●	00C5
MX-5 MIATA	1.8L	BP	1997 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	1999 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2000 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2001 MY	ABS/TCS	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2001 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2003 MY	ABS/TCS	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2003 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2005 MY	ABS/TCS	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2005 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2004 MY	ABS/TCS	●	●	●	●	○
MX-5 MIATA	1.8L	BP	2004 MY	PCM	●	●	●	●	○
MX-5 MIATA	1.8L	BP Turbo	2004 MY	ABS/TCS	●	●	●	●	○
MX-5 MIATA	1.8L	BP Turbo	2004 MY	PCM	●	●	●	●	○
PREMACY	1.8L	FP	1999 MY	ABS	●	●	●	●	○
PREMACY	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●	○
PREMACY	1.8L	FP	2000 MY	PCM	●	●	●	●	○
PREMACY	2.0L	RF-T	1999 MY	ABS	●	●	●	●	○
PREMACY	2.0L	RF-T	1999 MY	PCM	●	●	●	●	○
PREMACY	2.0L	RF-T	2000 MY	ABS	●	●	●	●	○
PREMACY	2.0L	RF-T	2000 MY	ABS/TCS	●	●	●	●	○
PREMACY	2.0L	RF-T	2000 MY	PCM	●	●	●	●	○
PREMACY	2.0L	RF-T	2003 MY	ABS/TCS	●	●	●	●	○
PREMACY	2.0L	RF-T	2003 MY	PCM	●	●	●	●	○
PREMACY	2.0L	FS	2001 MY	ABS	●	●	●	●	○
PREMACY	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●	○
PREMACY	2.0L	FS	2001 MY	PCM	●	●	●	●	○
PREMACY / IXION	1.8L	FP	1999 MY	ABS	●	●	●	●	○
PREMACY / IXION	1.8L	FP	1999 MY	PCM	●	●	●	●	○
PREMACY / IXION	1.8L	FP	2002 MY	ABS/TCS	●	●	●	●	○
PREMACY / IXION	1.8L	FP	2002 MY	PCM	●	●	●	●	○
PREMACY / IXION	1.8L	FP DE	1999 MY	ABS	●	●	●	●	○
PREMACY / IXION	1.8L	FP DE	1999 MY	PCM	●	●	●	●	○
PREMACY / IXION	2.0L	RF-T	1999 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PREMACY / IXION	2.0L	RF-T	1999 MY	PCM	●	●	●	●	○
PREMACY / IXION	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●	○
PREMACY / IXION	2.0L	FS	2001 MY	PCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	4X4	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	ACU	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	BCM/GEM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	EATC	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	EPS	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	IC	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	LPSDM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	RCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	RKE	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	RPSDM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	TCM	●	●	●	●	○
PREMACY / MAZDA5	2.0L	LF	Other	TCM	●	●	●	○	○
PREMACY / MAZDA5	1.6L	Y6	Other	4X4	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	ACU	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	BCM/GEM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	EATC	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	EPS	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	IC	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	LPSDM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	RCM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	RKE	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	RPSDM	●	●	●	●	○
PREMACY / MAZDA5	1.6L	Y6	Other	TCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PREMACY / MAZDA5	1.6L	Y6	Other	TCM	●	●	●	○	○
PREMACY / MAZDA5	1.8L	L8	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	ACU	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	BCM/GEM	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	EATC	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	EPS	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	IC	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	LPSDM	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	PCM	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	RCM	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	RKE	●	●	●	●	○
PREMACY / MAZDA5	1.8L	L8	Other	RPSDM	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	ABS	●	●	●	●	001E
PREMACY / MAZDA5	2.5L	L5	Other	ABS	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	ACU	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	BCM/GEM	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	EATC	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	EPS	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	IC	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	LPSDM	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	PCM	●	●	●	●	0009
PREMACY / MAZDA5	2.5L	L5	Other	RCM	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	RKE	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	RPSDM	●	●	●	●	○
PREMACY / MAZDA5	2.5L	L5	Other	TCM	●	●	●	○	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	4X4	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	ABS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	EATC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	EPS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	GEM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	IC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	PCM	●	●	●	●	0037 00C5 00C6
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	RCM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	4X4	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	ABS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	EATC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	EPS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	GEM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	IC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	LPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	PCM	●	●	●	●	0037 00C5 00C6
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	RCM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	RKE	●	●	●	●	0005
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	RPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2006 MY	TCM	●	●	●	●	00C5
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	4X4	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	ABS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	EATC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	EPS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	GEM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	IC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	LPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	PCM	●	●	●	●	0037 00C5 00C6
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	RCM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	RKE	●	●	●	●	0005
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	RPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.0L	LF	2007 MY	TCM	●	●	●	●	00C5
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	ABS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	EATC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	EPS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	GEM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	IC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	PCM	●	●	●	●	0037 00C5 00C6
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	RCM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2005 MY	RKE	●	●	●	●	0005
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	ABS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	EATC	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	EPS	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	GEM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	LPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	PCM	●	●	●	●	0037 00C5 00C6
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	RCM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	RKE	●	●	●	●	0005
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	RPSDM	●	●	●	●	○
PREMACY / MAZDA5 (Japan / General	2.3L	L3	2007 MY	TCM	●	●	●	●	00C5
PROBE / MX-6	2.0L	Other	1996 MY	PCM	●	●	●	●	0023 0025
PROBE / MX-6	2.0L	Other	1997 MY	PCM	●	●	●	●	0023 0025
PROBE / MX-6	2.5L	KL	1996 MY	PCM	●	●	●	●	○
PROBE / MX-6	2.5L	KL	1996 MY	PCM	●	●	●	●	○
PROBE / MX-6	2.5L	KL	1997 MY	PCM	●	●	●	●	○
PROBE / MX-6	2.5L	KL	1997 MY	PCM	●	●	●	●	○
PROCEED	2.5L	G5	1996 MY	PCM	●	●	●	●	○
PROCEED	2.6L	G6	1996 MY	PCM	●	●	●	●	○
PROTEGE	1.5L	Z5	1997 MY	PCM	●	●	●	●	○
PROTEGE	1.5L	Z5	1998 MY	PCM	●	●	●	●	○
PROTEGE	1.8L	BP	1997 MY	PCM	●	●	●	●	○
PROTEGE	1.8L	BP	1998 MY	PCM	●	●	●	●	○
PROTEGE	1.8L	FP	1999 MY	PCM	●	●	●	●	○
PROTEGE	1.8L	FP	2000 MY	ABS/TCS	●	●	●	●	○
PROTEGE	1.8L	FP	2000 MY	PCM	●	●	●	●	○
PROTEGE	1.6L	ZM	1999 MY	PCM	●	●	●	●	○
PROTEGE	1.6L	ZM	2000 MY	ABS/TCS	●	●	●	●	○
PROTEGE	1.6L	ZM	2000 MY	PCM	●	●	●	●	○
PROTEGE	1.6L	ZM	2001 MY	ABS/TCS	●	●	●	●	○
PROTEGE	1.6L	ZM	2001 MY	PCM	●	●	●	●	○
PROTEGE	2.0L	FS	2001 MY	ABS/TCS	●	●	●	●	○
PROTEGE	2.0L	FS	2001 MY	PCM	●	●	●	●	○
PROTEGE	2.0L	FS	2002 MY	ABS/TCS	●	●	●	●	○
PROTEGE	2.0L	FS	2002 MY	PCM	●	●	●	●	○
PROTEGE	2.0L	FS	2003 MY	ABS/TCS	●	●	●	●	○
PROTEGE	2.0L	FS	2003 MY	PCM	●	●	●	●	○
PROTEGE	2.0L	FS T	2003 MY	ABS/TCS	●	●	●	●	○
PROTEGE	2.0L	FS T	2003 MY	PCM	●	●	●	●	○
Ranger	2.3L	DURATEC-HE / I4	2009.5 MY	4X4	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	ABS/TCS	●	●	●	●	0008
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	GEM	●	●	●	●	○
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	IC	●	●	●	●	0009
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	PCM	●	●	●	●	0023 0025
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	RCM	●	●	●	●	○
Ranger	2. 3L	DURATEC-HE / I4	2009. 5 MY	TBM	●	●	●	●	○
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	ABS/TCS	●	●	●	●	0008
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	ESOF	●	●	●	●	○
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	PCM	●	●	●	●	0009 0023 0025
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2004 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	IPC	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	RCM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	Other	Other	2011 MY	TRM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	3.0L	Other	1995 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	3.0L	Other	1996 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	3.0L	Other	1997 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	3.0L	Other	1998 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	1999 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2001 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	PCM	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2002 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	PCM	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2003 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2000 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	PCM	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2004 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	PCM	●	●	●	●	0010 0023 0028 0031
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2005 MY	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	PCM	●	●	●	●	0009 0023
Ranger / Mazda B Series / Courier	3.0L	Other	2006 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2007 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	GEM / SJB	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	Other	2008 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	GEM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	FFV	1999 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	3.0L	FFV	2000 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	4.0L	Other	1996 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	4.0L	Other	1997 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	4.0L	Other	1998 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	ABS/TCS	●	●	●	●	0008

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	1999 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	2000 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	PCM	●	●	●	●	0009 0023 0025
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	2001 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	Other	2002 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	GEM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	RAP	●	●	●	●	000A 000F
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2003 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2004 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	PCM	●	●	●	●	0010 0023 0028 0031
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2005 MY	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	PCM	●	●	●	●	0009 0023
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2006 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2007 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2008 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2009 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2010 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	IC	●	●	●	●	0009

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	4.0L	V6 SOHC	2011 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	PATS	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PCM	●	●	●	●	0010 0028 0031 0033

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	ABS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	ACM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	BCMii	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	DDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	FCDIM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	HVAC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	IPC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PAM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	PDM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	RCM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	SRM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	TBM	●	●	●	○	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	TCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.5L	DURATEC-HE / I4	2011 MY	TRM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1997 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	1996 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	Other	2001 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	ABS/TCS	●	●	●	●	0008

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	Other	2002 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	PCM	●	●	●	●	0009 0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	RAP	●	●	●	●	000A 000F
Ranger / Mazda B Series / Courier	2.3L	Other	2003 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	OHC	1995 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	IAB	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	PCM	●	●	●	●	0023 0025
Ranger / Mazda B Series / Courier	2.3L	OHC	1997 MY	RAP	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	PCM	●	●	●	●	0009 0023 0025
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	PCM	●	●	●	●	0010 0023 0028 0031
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	TPM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	IC	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM	●	●	●	●	0010 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	PCM	●	●	●	●	0023
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2006 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	GEM	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2007 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2008 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	ABS/TCS	●	●	●	●	0008
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	IC	●	●	●	●	0009

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	RCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	ABS	●	●	●	●	0008 0012
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	GEM / SJB	●	●	●	●	000A 0042
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	IC	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	OCSM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	PCM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	PCM	●	●	●	●	0010 0023 0025 0028 0031 0033
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	RCM	●	●	●	●	000C
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2011 MY	SDARS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	4X4	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	ABS/TCS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	GEM	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	PATS	●	●	●	●	○
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	PCM	●	●	●	●	0009
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RAP	●	●	●	●	000A
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ACM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	BCMii	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	DDM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	FCDIM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	HVAC	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	IPC	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PAM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PCM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PDM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	RCM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	SRM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TBM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TCM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TRM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	ACM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	BCMii	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	DDM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	FCDIM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	HVAC	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	IPC	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PAM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PCM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	PDM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	RCM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	SRM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TBM	●	●	●	○	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TCM	●	●	●	●	○
Ranger/_Mazda_B_Series/_Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011 MY	TRM	●	●	●	●	○
ROADSTER / MX-5	1. 6L	B6	2000 MY	ABS	●	●	●	●	○
ROADSTER / MX-5	1. 6L	B6	2002 MY	ABS/TCS	●	●	●	●	○
ROADSTER / MX-5	1. 6L	B6	2002 MY	PCM	●	●	●	●	○
ROADSTER / MX-5	1. 8L	BP	2000 MY	ABS	●	●	●	●	○
ROADSTER / MX-5	1. 8L	BP	2002 MY	ABS/TCS	●	●	●	●	○
ROADSTER / MX-5	1. 8L	BP	2002 MY	PCM	●	●	●	●	○
ROADSTER / MX-5	1. 8L	BP Turbo	2003 MY	ABS/TCS	●	●	●	●	○
ROADSTER / MX-5	1. 8L	BP Turbo	2003 MY	PCM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	ABS	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	IC	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	PCM	●	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RCM	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RHT	●	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	RKE	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2005 MY	TCM	●	●	●	●	00C5
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	ABS	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	IC	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	PCM	●	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RCM	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RHT	●	●	●	●	○
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	RKE	●	●	●	●	0005
ROADSTER / MX-5 (Japan / General Specs.)	2.0L	LF	2008 MY	TCM	●	●	●	●	00C5
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	ABS/TCS	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	EPS	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	IC	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	PCM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RCM	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	SASM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP High-Power	2003 MY	TCM	●	●	●	●	00C5
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	ABS/TCS	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	ABS/TCS	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	EPS	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	IC	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	PCM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	RCM	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	SASM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B-MSP Standard Power	2003 MY	TCM	●	●	●	●	00C5
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	ABS/TCS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	EPS	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	IC	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	LCM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	PCM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RCM	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	RKE	●	●	●	●	0005
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	SASM	●	●	●	●	○
RX-8 (Europe / General / Japan Specs.)	654x2cc	13B	2008 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2004 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2005 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	SASM	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2006 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2007 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP High-Power	2008 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2004 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	ABS/TCS	●	●	●	●	0005

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	IC	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B-MSP Standard Power	2005 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B	2009 MY	ABS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2009 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2009 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	IC	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	LCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2009 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2009 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2009 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2009 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B	2009 MY	TPM	●	●	●	●	0005 001A
RX-8 (North America Specs)	654x2cc	13B	2009 MY	TPM	●	●	●	○	0005 001A
RX-8 (North America Specs)	654x2cc	13B	2010 MY	ABS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2010 MY	ABS/TCS	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2010 MY	EPS	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	IC	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	LCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	PCM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	RCM	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2010 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2010 MY	RKE	●	●	●	●	0005
RX-8 (North America Specs)	654x2cc	13B	2010 MY	SASM	●	●	●	●	○
RX-8 (North America Specs)	654x2cc	13B	2010 MY	TCM	●	●	●	●	00C5
RX-8 (North America Specs)	654x2cc	13B	2010 MY	TPM	●	●	●	●	0005 001A
RX-8 (North America Specs)	654x2cc	13B	2010 MY	TPM	●	●	●	○	0005 001A

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
SCRUM	660cc	F6A	1999 MY	ABS	●	●	●	●	○
SCRUM	660cc	F6A	1999 MY	PCM	●	●	●	●	○
SCRUM	660cc	F6A	1999 MY	PCM	●	●	●	●	○
SCRUM	660cc	F6A	1999 MY	RCM	●	●	●	●	○
SCRUM	660cc	F6A	Other	ABS	●	●	●	●	○
SCRUM	660cc	F6A	Other	PCM	●	●	●	●	○
SCRUM	660cc	F6A	Other	PCM	●	●	●	●	○
SCRUM	660cc	F6A	Other	RCM	●	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	ABS	●	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	PCM	●	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	RCM	●	●	●	●	○
SCRUM	660cc	F6A-T	1999 MY	TCM	●	●	●	●	○
SCRUM	660cc	F6A-T	Other	ABS	●	●	●	●	○
SCRUM	660cc	F6A-T	Other	PCM	●	●	●	●	○
SCRUM	660cc	F6A-T	Other	PCM	●	●	●	●	○
SCRUM	660cc	F6A-T	Other	RCM	●	●	●	●	○
SCRUM	660cc	F6A-T	Other	TCM	●	●	●	●	○
SCRUM	660cc	K6A	2001 MY	ABS	●	●	●	●	○
SCRUM	660cc	K6A	2001 MY	PCM	●	●	●	●	○
SCRUM	660cc	K6A	2001 MY	RCM	●	●	●	●	○
SCRUM	660cc	K6A	Other	ABS	●	●	●	●	○
SCRUM	660cc	K6A	Other	PCM	●	●	●	●	○
SCRUM	660cc	K6A	Other	PCM	●	●	●	●	○
SCRUM	660cc	K6A	Other	RCM	●	●	●	●	○
SCRUM	660cc	K6A	2005 MY	ABS	●	●	●	●	○
SCRUM	660cc	K6A	2005 MY	PCM	●	●	●	●	○
SCRUM	660cc	K6A	2005 MY	RCM	●	●	●	●	○
SCRUM	660cc	K6A T	2001 MY	ABS	●	●	●	●	○
SCRUM	660cc	K6A T	2001 MY	PCM	●	●	●	●	○
SCRUM	660cc	K6A T	2001 MY	RCM	●	●	●	●	○
SCRUM	660cc	K6A T	2001 MY	TCM	●	●	●	●	○
SCRUM	660cc	K6A T	Other	ABS	●	●	●	●	○
SCRUM	660cc	K6A T	Other	PCM	●	●	●	●	○
SCRUM	660cc	K6A T	Other	RCM	●	●	●	●	○
SCRUM	660cc	K6A T	Other	TCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	PCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	PCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005 MY	RCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	2005 MY	ABS	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	2005 MY	PCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	2005 MY	RCM	●	●	●	●	○
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A T	2005 MY	TCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	Other	ABS	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	Other	PCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	Other	PCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	Other	RCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	2003 MY	ABS	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	2003 MY	PCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A	2003 MY	RCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	Other	ABS	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	Other	PCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	Other	RCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	Other	TCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	2003 MY	ABS	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	2003 MY	PCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	2003 MY	RCM	●	●	●	●	○
SCRUM (2003 / 9 -)	660cc	K6A T	2003 MY	TCM	●	●	●	●	○
SENTIA	3. 0L	JE	1997 MY	PCM	●	●	●	●	○
SENTIA	3. 0L	JE HO	1997 MY	PCM	●	●	●	●	○
TITAN DASH	2. 0L	FE	2000 MY	PCM	●	●	●	●	○
TITAN DASH	2. 0L	FE	2002 MY	PCM	●	●	●	●	○
TITAN DASH	2. 0L	FE	2002 MY	TCM	●	●	●	●	○
TITAN DASH	2. 0L	FE LPG	2002 MY	PCM	●	●	●	●	○
TITAN DASH	2. 0L	FE LPG	2002 MY	TCM	●	●	●	●	○
TITAN DASH	2. 0L	RF-T	2004 MY	PCM	●	●	●	●	○
TITAN DASH	2. 0L	RF-T	2004 MY	TCM	●	●	●	●	00C5
TITAN_DASH	2. 0L	RF-T	2004. 5 MY	PCM	●	●	●	●	○
TITAN_DASH	2. 0L	RF-T	2004. 5 MY	TCM	●	●	●	●	00C5
XEDOS9	2. 0L	KF	1996 MY	ABS	●	●	●	●	○

MaxiDas_Mazda_V5.10 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
XEDOS9	2.3L	KJ	1996 MY	ABS	●	●	●	●	○
XEDOS9	2.3L	KJ	1998 MY	ABS	●	●	●	●	○
XEDOS9	2.5L	KL	1996 MY	ABS	●	●	●	●	○
XEDOS9	2.5L	KL	1998 MY	ABS	●	●	●	●	○
XEDOS9	2.5L	KL	2000 MY	ABS	●	●	●	●	○
XEDOS9	2.5L	KL	2000 MY	ABS/TCS	●	●	●	●	○
XEDOS9	2.5L	KL	2000 MY	PCM	●	●	●	●	○

Special_Function

index	Specil Function Name	index	Specil Function Name
0005	Programmable Module Installation	00CB	PDC Reset
0006	Module Reprogramming	00CC	Steering Wheel Position Sensor Calibration
0007	Programmable Parameters	00CD	Preliminary Checks
0008	ABS Service Bleed	00CE	Reset TCM KAM
0009	PATS Functions	00CF	Fuel System Prime
000A	Remote Keyless Entry	0101	Audio
000B	G Sensor Calibration	0102	Battery saver
000C	Passenger System Reset	0103	Body Type
000D	Neutral Position Setting	0104	Courtesy Lamp
000E	Ride Height Calibration	0105	Door Trigger Disable Mode
000F	Factory Keyless Entry Code	0106	Body and Fuel Type
0010	Stop Use of Transmission Adaptive	0107	Hazard Warning
0011	Power Seat Calibration	0108	Horn Warning
0012	IVD Initialization Sequence	0109	Master Door Trigger Disable Mode
0013	Pneumatic Test	010A	Panic Alarm
0014	Accurate Trim Test	010B	Police Mode
0015	Passenger Zero Seat Weight Test	010C	Traction control system
0016	Microphone Test	010D	Autolamp Off Setting
0017	Audio Speaker Walkaround Test	010E	Autolamp On Setting
0018	Infotainment Display Test	010F	Police Speedometer Offset
0019	Tones Test	0110	Cabin Temperature Sensor Calibration Factor
001A	TPMS Functions	0111	Taxi Mode
001B	Zero Speed Test	0112	Low Coolant Warning
001C	Rear Tones Test	0113	Parking Brake Warning
001D	Monotones Test	0114	Headlamp Delay Door Open
001E	Sensor Initialization	0115	Headlamp Delay Ignition Off
001F	EPB calibration.	0116	Headlamp Delay Remote Lock Pressed
0020	EATC Operation Check	0117	Dynamic Stability Control
0021	Rain Sensor Reset	0118	Hill Descent Control LED
0022	LPSDM and RPSDM Service Function	0119	Brake System Configuration
0023	Power Balance	011A	BPM fitted
0024	EVAP Test	011B	Camera fitted
0025	Reset PCM KAM	011C	Audio Interface Module
0026	OBDII Modes	011D	Sonar fitted
0027	Clear Transmission Adaptive	011E	Navigation System
0028	Clear Transmission Adaptive Tables	011F	Parking Aid Module
0029	Configure All Three Sensors Together.	0120	Odometer Write
002A	Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors.	0121	Subwoofer
002B	Configure the lateral acceleration sensor.	0122	Driver Beltminder Status
002C	Configure the pressure sensor.	0123	Alarm
002D	FFH SelfTest and Prefill Utility	0124	Audio Configure
002E	FFH Start Heater Utility	00AF	Reset the air conditioning compressor learned values.
002F	FFH Unlock Utility	00B0	Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values
0030	Auxiliary vehicle ID reset	00B1	Reset the Exhaust Gas Temperature Value
0031	Halt Transmission Adaptive Learning	00B2	Reset the Fuel Injection Pump Learned Values
0032	Headlamp Alignment	00B3	Reset the Fuel Injector Learned Values
0033	Resume Transmission Adaptive Learning	00B4	Reset the Fuel Metering Valve Learned Values
0034	Resume Transmission Adaptive Tables	00B5	Reset the Fuel Pressure Relief Valve Open Count Learned
0035	Keyfob Training	00B6	Reset the Fuel Pressure Relief Valve Open Duration Learned Value
0036	Transmission	00B7	Reset the Fuel Rail Pressure Sensor Learned Values
0037	Transmission Learning	00B8	Reset the Heated Exhaust Gas Oxygen Sensor Learned Values
0038	Transmission Solenoid Body IDN	00B9	Reset the Mass Air Flow Sensor Learned Values
0039	VSM Service Functions	00BA	Reset the Neutral Gear Position Learned Value
003A	A/C Test	00BB	Reset the oil change indicator.
003B	ACM	00BC	Reset the Powertrain Control Module Learned Values

Special_Function

index	Specil Function Name	index	Specil Function Name
003C	ACM Security Bypass Test	00BD	Reset the Turbocharger Learned Values.
003D	Air/Fuel Learning	00BE	Reset the Turbocharger Variable Vane Actuator Learned
003E	AM Antenna Reception Sensitivity Test	00BF	Reset the Turbocharger Variable Vane Position Sensor Learned Values
003F	ASM Service Functions	00C0	Reset the Vehicle Speed Limit
0040	audio configuration	00C1	Reset the water in fuel Warning Indicator.
0041	Auto Leveling Sensor Re-zero Procedure	00C2	rpm Controller
0042	Tire pressure monitoring system	00C3	Stop-Start Activation
0043	BSM Radar Test	00C4	Speed Limiting
0044	Button Test	00C5	TR Sensor Test
0045	CAN Bus Fault Test	00C6	Transmission Fluid Level Test
0046	CCM Calibration	00C7	Automatic Transmission PRNDL Display Test
0047	Clear EGR Adaptive Tables	00C8	BSI Solenoid Test
0048	Clear Fuel Injector & HP Pump Adaptive Tables	00C9	Automatic Transmission Park Switch Test
0050	Clearing of Learning Value	00CA	ABS reset and configuration.
0051	Component/Parameter Reset	0099	Reset the Exhaust Gas Recirculation Valve Learned Values
0053	Configure the steering angle	009A	Reset the Intake Air Throttle Valve Learned Values
0054	Configure the yaw rate sensor.	009B	Reset / Clear Specified Function
0055	Data Reset	009C	SCR Dosing Measurement Test
0056	DPF	009D	SCR Parameter Reset
0057	DPF Component Parameter	009E	SCR System Emptying
0058	DPF Manual Regeneration	009F	SCR System Refill Activation
0059	DPF Parameter Reset	00A0	SCR Visual Leak Check
005A	Electronic Throttle Control	00A1	System Prime
005B	EPS Steering Angle Calibration	00A2	WIF Reset
005C	ETB/EGR Initialization	00A3	DPF Reset
005D	FACM	00A4	Enter the Fuel Injector Default Count Value
005E	FFH Operation Check	00A5	Clutch Switch Learn
005F	Gauge Test	00A6	Engine Oil Quality History
0060	ICCM Aiming Adjustment	00A7	Fuel Injection Pump Learn
0061	Illumination Test	00A8	Fuel Injector Pilot Correction Learn
0062	Input and Data Test	00A9	Fuel System Leak Test
0063	Interior Scan Test	00AA	Initialize the Exhaust Gas Related Component.
0064	Keyless Entry Keypad Code Reset	00AB	Reset Differential Pressure Sensor Learned Values
0065	Learning	00AC	Reset KAM
0066	Misfire Check	00AD	Reset MAF Sensor Drift.
0067	Misfire Monitor Neutral Profile Correction	00AE	Reset MAF Sensor Offset.
0068	Module Identification	0082	Mode 8 - On-Board device control
0069	Multifunction Output Test	0083	Mode 9 - Vehicle Information
006A	Network Test	0084	OBD Drive Cycle
006B	New FACM	0085	Service Functions
006C	Parking Aid Switch Test	0090	Diesel Particulate Filter Static Regeneration
006D	Passenger Seat Weight Sensor ReZero	0091	DPF Regeneration Suspension
006E	Rebalance	0092	Fuel Injector Correction Factors
006F	Reset the Knock Sensor Learned Values	0093	IQA
0070	Reset Transmission Tables	0094	Refill the FAT.
0071	Resetting adaptive values	0095	Relearn Vehicle Data
0072	RVM Aiming	0096	Reset Charge Air Cooler Bypass Valve Position Offset.
0074	Service Routine	0097	Reset the Cooling Fan Motor Learned Values
0075	Special Ignition ON	0098	Reset the Diesel Particulate Filter Learned Values
0076	Steering angle sensor calibration	0080	Mode 1 Powertrain Data
0077	Supplemental Heater Test	0081	Mode 6 On-Board Test Results