



MaxiDas_Subaru_V2.00 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

System Name	Read Codes	Erase Codes	Live Data	Special Function
Engine Control System	●	●	●	0001, 0002, 0003, 0004, 0005
Transmission Control System	●	●	●	0005
Brake Control System	●	●	●	0006, 0007
Integ.unit mode	●	●	●	0008, 0009
Airbag System	●	●	○	0010
CAN SYSTEM	●	○	○	0011
Cruise Control System	●	○	●	0003
Keyless access system	●	●	●	
Power Steering System	●	●	●	0007
Tire Pressure Monitor	●	●	●	0013
Occupant Detection System	○	○	○	0012



Special_Function

index	Specil Function Name	index	Specil Function Name
0001	System Operation Check Mode	0008	Integ.Unit customizing
0002	Dealer Check Mode Procedure	0009	Function Check
0003	Cancel code(s) Display	0010	Status data
0004	Diagnosis Results	0011	Fault Location
0005	OBD SYSTEM	0012	Re-zeroing
0006	Function Check Sequence	0013	Transmitter ID regist confirm
0007	Freeze Frame		